THE SHARPER IMAGE®

Variable Lighting 5x Travel Mirror

CA871 Instructions



Read and save these instructions.

Dear Sharper Image Customer,

Thank you for your purchase of a Sharper Image product. We appreciate your business very much.

Please accept my personal assurance of your complete satisfaction with this product's quality and performance. We offer generous return privileges and excellent warranties on all our products.

For more than 25 years, The Sharper Image has shared the fun of discovering innovative products that make life easier and more enjoyable. We've been in business a long time because we are an exciting place to shop and — just as importantly — we strive to deliver great customer service that exceeds your expectations.

Enjoy your purchase!

Respectfully,

Richard

Richard Thalheimer
Founder, Chairman and Chief Executive Officer

Call 1-800-344-4444 for 24-7 ordering and customer service, or go to **www.sharperimage.com**, *our complete online store.*

Installing Batteries

Remove the battery cover on the bottom of the mirror by inserting finger into recess and pressing and lifting cover away from the mirror housing.

Insert 4 AA batteries, observing proper +/- polarities according to illustration inside the battery compartment. Replace the battery cover when batteries have been installed.

Optional DC Adapter

Mirror can also be plugged into an outlet using a 6V DC adapter (purchase separately).

Mirror Use

1. Open the case.
2. To turn the mirror on, press the **ON/OFF** button.
3. To adjust color of light, slide the color adjustment switch right or left — left for day, right for evening.
4. When finished using the mirror, press the **ON/OFF** button again to turn the mirror off.

Care and Maintenance

Clean mirror with a damp, soft cloth as needed.

Never use harsh chemical cleaners or abrasives as they may damage the surface of the mirror.

Remove batteries and store unit in a cool, dry place if mirror will not be used for a long period of time.

Mirror comes with long-life bulbs that should not require any maintenance. Do not attempt to repair or replace bulbs.

WARRANTY

What Is Covered

This warranty covers any defects in materials or workmanship, with the exceptions stated below.

How Long Coverage Lasts

This warranty runs for 90 days from the date of original purchase.

What Is Not Covered

This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, or loss or damage to batteries or removable parts.

What The Sharper Image Will Do

The Sharper Image will repair any defects in materials or workmanship. In the event repair is not possible, The Sharper Image will either replace this product with one of similar features and price, or refund the full purchase price of the product, whichever you prefer.

How to Obtain Service

Return the product and receipt, along with a brief explanation of the problem, to:

T.S.I. - Returns Department
2901-A West 60th Street
Little Rock, AR 72209

If you have questions please feel free to contact our customer service representatives at 1-800-344-5555 or by email at care@sharperimage.com.

This warranty gives you specific legal rights, and you may have other legal rights that vary from state to state.

Copyright 2003

Sharper Image Corporation
650 Davis St., San Francisco, CA 94111
(415) 445-6000

Shop online: **www.sharperimage.com**

Due to continuing improvements, actual product may differ slightly from the product described herein.
V2 05/03